

## Atwood RV AC Installation Instructions

- 1) Locate White Compressor wire on the Compressor and follow to electrical box Run Capacitor “**C**” terminal. Disconnect and splice White wire connection to the Brown ICM soft start wire.
- 2) Connect Red ICM soft start wire to the location of the previous White Compressor wire terminal on the Run Capacitor “**C**” terminal.
- 3) Connect Blue soft start wire to the “**H**” terminal on the Run Capacitor.
- 4) **IF** you see a second Red wire next to the Red Compressor Wire, disconnect it and seal end with electrical tape.
- 5) Follow Black Compressor wire to Circuit Board COM port terminal. Cut wire and 3-way splice Black ICM soft start wire in a convenient location along the wire.