

Emerson Installation Instructions

- 1) Locate White Compressor wire on the Compressor and follow to electrical box Run Capacitor "C" terminal. Disconnect and splice White wire connection to the Brown ICM soft start wire.
- 2) Connect Red ICM soft start wire to the location of the previous White Compressor wire terminal on the Run Capacitor "C" terminal.
- 3) Disconnect the Red Compressor wire from the "H" terminal on the Run Capacitor. Connect Blue ICM soft start wire on that terminal. Reconnect the Red Compressor wire onto the Piggyback connector of the Blue ICM soft start wire.
- 4) **IF** you see a second Red wire next to the Red Compressor wire, disconnect it and seal end with electrical tape.
- 5) Locate the 3rd wire coming out of the Compressor overload switch (may be Blue or Black), route and 3-way splice the final Black soft start wire to a convenient location along the Compressor's (Blue or Black) wire.